

Following is a listing of all system configurations for Plus Sine Upgrades (to existing Sine Systems RFC units) and new Plus Sine Remotes.

Plus Sine Upgrade 8

(The hardware and software that allows your existing 8 channel Sine System Remote to communicate with the New Plus Sine Software)

- 1 Sine Systems RS232 Serial Communications Adapter
- 1 Sine Systems AD-8 Telemetry Interface
- 1 Plus Sine Software Package

Plus Sine Upgrade 16

- 1 Sine Systems RS232 Serial Communications Adapter
- 2 Sine Systems AD-8 Telemetry Interface
- 1 Plus Sine Software Package (Basic program to control first AD-8)
- 1 Plus Sine +8 Channels (Allows metering of the next AD-8 + 16 more relays)

New Plus Sine 8 Channel Package

- 1 Sine Systems RS232 Serial Communications Adapter
- 1 Sine Systems RFC-1/B Remote Facilities Controller (main unit)
- 1 Sine Systems RP-8 Relay Panel (8 telemetry inputs and 8 pairs of control relay outputs)
- 1 Sine Systems SP-8 Surge Protector (with telephone line protection)
- 1 Sine Systems AD-8 Telemetry Interface
- 1 Plus Sine Software Package

New Plus Sine 16 Channel Package

- 1 Sine Systems RS232 Serial Communications Adapter
- 1 Sine Systems RFC-1/B Remote Facilities Controller (main unit)
- 2 Sine Systems RP-8 Relay Panel (8 telemetry inputs and 8 pairs of control relay outputs)
- 1 Sine Systems SP-8 Surge Protector (with telephone line protection)
- 1 Sine Systems SP-8/TO Surge Protector without telephone line protection
- 2 Sine Systems AD-8 Telemetry Interface
- 1 Plus Sine Software Package (Basic program to control first AD-8)
- 1 Plus Sine +8 Channels (Allows metering of the next AD-8 + 16 more relays)